



VIENNA WOODS LEVELLING INSTRUCTIONS

WOOD SUBFLOORS

All surfaces need to be paint and dust free.

PRIMER (Mapeiprim A + B)

Use Mapeiprim SP 2 pack, i.e. some of each part as per instructions (will not set properly otherwise).

Mix only the amount needed for priming the area you are working on.

Primer has to be dry for about 1 hour – depends on temperature.

When primer is dry the surface will be glossy and transparent.

RAMPING (Nivorapid + Latex)

To do ramping, mix Nivorapid with Latex until the compound has the right thickness for the job. This is NOT self-levelling compound.

SELF-LEVELLING

For uneven surfaces use Fibreplan self-levelling compound.

Mix to the instructions on the back of the bag (5.5 litres of water).

Subfloors need to be primed with Mapeiprim SP first.

If applying Fibreplan over ramping done with Nivorapid, you do not have to prime first if done within 24 hours. If 24 hours has passed then primer must be applied first.

Fibreplan needs to be sanded after it has hardened and set.

Only use at a maximum of 10mm for each coat – no need to prime in between if applying Fibreplan to Fibreplan.

NOTE: All holes and gaps in subfloor need to be covered with Nivorapid first before using self-levelling compound.

CONCRETE SUBFLOORS

All surfaces need to be paint and dust free.